



Sealing Joinery in Oak frame

IMPORTANT

Please make sure Compriband Tape is inserted into groove around window frame before windows are fitted into Oak Frame.

1. Check window frame fits into correct aperture.
Before fixing frame, insert Compriband into groove.

2. Position window in aperture & screw through rebates of frame to fix.

Note:

Leave screws loose (tighten & then back off a couple of turns)
to avoid distortion of the frame.

3. Run Silicone Bead between window & Oak Frame internally & externally.

4. Fit Trim Beads internally & externally.

