



Full Frame

This frame was a full frame planted on to the outside of an existing property with an additional new frame to transform a dull 1960's farmhouse into a Tudor style property with Georgian extension.

The history of oak framing was to show the oak on the outside to indicate to neighbours how wealthy the owner was. We believe that the beauty of oak should be seen by those that paid for it!

This frame was a 75mm thick plant on but half lapped so that any shrinkage of the timbers would still look like a full oak frame behind.

75mm Half Lapped



We wouldn't recommend using oak boards as 'plant on' features on traditional brick and block buildings due to the probable shrinkage of the oak boards.

This reveals the structure behind and after a short period of time makes the building look 'cheap'.



Albion Oak

Plant on Oak